



- Assemble as illustrated above.
- Insert your switch with the tabs aligned to the prongs.
- Press firmly down until the switch is fully seated.
- Release and pull the top half of the switch case away.
- Remove the bottom half of the switch by pulling up on its corners.



 **VIDEO GUIDE**
youtu.be/wummmfLXDSI